

Before you use your case please perform the following waterproof test.

How to test

- Check the watertight seal. Make sure the seal is clean of any fine hairs, dust, crumbs or other foreign material.
- Place the enclosed card into the case and close the seal tightly. Fold the plastic flaps across the crease lines and then secure in place with the velcro strip.
- Use a water container / basin such as a kitchen sink to submerge the case.
- Upon removal take care to wipe any water away from the opening of the case.
- 5. Point the case in a downward position before opening the mouth so that no trapped water will enter into the case.
- Open the mouth. There should be no water inside the case. There may be slight moisture due to humidity if the water temperature differs from the room temperature.
- Check that the card inside the case is dry. If so the case is ready for use with your smart device.

Caution

Check for damage to the case after each use. Ensuring that there are no puncture's to the back and front. And that the seal to the mouth of the case has been unaffected.

Do not expose for long periods under direct sunlight as this may damage the plastic.